

## UNPACKING YOUR WHEELIESAFE 'MANUAL' TROLLEY

Because of their awkward shape the MANUAL trolley has to be slightly disassembled for transport.

However, reassembly is quite simple and requires only a shifter and a Phillips screwdriver, or two shifters.

**The white brake clip may have become dislodged from the trolley handle bar during transport. Care should be taken to retrieve it from the packaging before it is discarded.**

Once the trolley is removed from its carton it will appear as shown below:



Cut the two electrical ties and lift out the Handling Bracket and the Cargo Bar.

Rotate the Third Wheel Assembly through 300 degrees so that it is at the rear of the trolley shafts. Undo the two nut, bolt and washer assemblies on the clamp arrangement and re-fit the clamp over the

bar located at about the centre of the shafts, as shown in the illustration below.



Now attach the Cargo Bar to the drilled lugs on the lower section of the trolley's shafts, using the four bolt and nut assemblies provided.

The assembled trolley should appear as shown below:



If you have any queries or questions, please contact Brian Stafford at [bstafford@wheeliesafe.com.au](mailto:bstafford@wheeliesafe.com.au) or on 0417 383 957.